

Z Scanner with ViewSonic Touchscreen

Product:	Z series scanners with TM, TX and TZ printers when used with a ViewSonic Touchscreen.
Overview:	The Assembly Guide and SmartWorks MFP software Help assumes installation and operation with a system controller. When using a ViewSonic Touchscreen with a separate PC please review the following notes:
Min PC Spec:	CPU = Intel Pentium G5400T, SSD = 256GB, RAM = 8GB. Windows 10® or Windows 11®.

Assembly Instructions exceptions:

Follow the Assembly Instructions & Start-Up Guide noting the exceptions listed below especially the routing of the cables:

- Fit the ViewSonic Touchscreen in place of the AIO to the supplied wider VESA arm as follows:
 1. Remove two bottom screws from the Touch Screen. Half unscrew the top two screws.
 2. Hook Touch Screen to VESA Arm over the top screws according to the printer model as shown below. Re-fit bottom screws and tighten all four screws.



TX-2100/3100/4100, TM-200/205/300/305



TZ-30000

- ViewSonic Touchscreen Cables:
 - Power cable from the external power supply using the supplied IEC C13 to C6 adapter to connect to the 3-1 Power Cable.



- USB cable for touch screen operation – connect to the PC.
- Video cable – connect to the PC.

- PC Cables:
 - USB3 cable to scanner.
 - Ethernet cable to network and printer or USB cable for printer.
 - Video and USB cables from ViewSonic Touchscreen.

Start-Up Guide exceptions:

- Download and install the latest version of SmartWorks MFP v6 software from <http://www.mfpdownload.com/>
(Do not use the “image file” as that is for system controllers only).
- Install the Canon printer driver for the connected printer and then use Settings - Printer Settings - Printer Setup to select.

SmartWorks MFP Operational differences:

System Controller options	Open System options
Home Page Drop Down Menu	
<ul style="list-style-type: none"> • Sleep • Restart • Shutdown 	<ul style="list-style-type: none"> ○ Exit (Exits the software, but does not affect the PC).
Settings - System Administration	
<ul style="list-style-type: none"> • Local folder browsing • System Update and Recovery • Set Date and Time • Time Zone • System IP 	<ul style="list-style-type: none"> ○ NA - Browsing is always on ○ NA - Manual process ○ NA - Use standard PC methods
Global Scanning’s Ghostscript PDF license key upgrade	
<ul style="list-style-type: none"> • Available 	<ul style="list-style-type: none"> ○ NA

NA = Not Available